

TEMPORARY / PERMANENT 1 PHASE UNDERGROUND METER INSTALLATION

COOPERATIVE WILL:
FURNISH AND INSTALL
METER SERVICE WIRE. ALL
CONNECTIONS INSIDE OF
TRANSFORMER, PEDESTAL
OR DIP POLE

NOTE: MVEC WILL DO THE WIRE
INSTALLATION INSIDE THE
TRANSFORMER, PEDESTAL OR FROM
THE DIP POLE.

MEMBER WILL:
FURNISH & INSTALL METER BASE AND BOND IT TO
GROUND. FURNISH AND INSTALL ALL REQUIRED
MATERIALS.

NOTE:
ALL BASES AND DEVICES SHALL BE BONDED
TO GROUND.

TRENCH, BACKFILL, FURNISH AND INSTALL
2 1/2" CONDUIT (SCHEDULE 40 PVC) TO
ACCOMMODATE 1/0 TO 350 MCM SERVICE.
FURNISH PULL STRING FROM THE METER
AS REQUIRED TO THE UNDERGROUND
TRANSFORMER, PEDESTAL OR DIP POLE.

