

UNDERGROUND GROUP METERING (MAXIMUM 6 METERS)

COOPERATIVE WILL:
CONNECT THE SERVICE CONDUCTOR TO THE MEMBER'S CONDUCTORS IN THE JUNCTION BOX AND ONLY TO A SINGLE SET OF CONDUCTORS, AND INSTALL SERVICE IN ACCORDANCE WITH THE COOPERATIVE'S STANDARD UNDERGROUND SERVICE POLICY.

MEMBER WILL:
FURNISH AND INSTALL SEALABLE RAIN TIGHT TROUGH, JUNCTION BOX AND ALL REQUIRED SERVICE ENTRANCE MATERIAL. INSTALL AND FURNISH METER BASE. ALL BASES AND DEVICES SHALL BE BONDED. FURNISH AND INSTALL CONDUIT (F&I) FROM JUNCTION BOX TO UNDERGROUND TRANSFORMER, PEDESTAL, OR DIP POLE. (SEE DRAWING UNDERGROUND METER INSTALLATION FOR LIMITS) IDENTIFY METER BASE IN ACCORDANCE WITH "IDENTIFICATIONS" PAGE 16.

